# Driver Installation on Windows 8 or 8.1

If there is a message popup during the installation of driver such as the message show below, it will be required to disable the Driver Signature Enforcement in Windows 8 or 8.1 before proceeding of driver installation.


Procedure

1. Open the Windows 8 Settings panel by pressing the Windows key + I keyboard combination . Click on **Change PC Settings.**

2. The PC settings panel will show up. Have the computer restart with steps as illustrated below for Window 8 or Window 8.1 respectively.

<u>Windows 8</u>

Select the **General** option, locate the "Advanced startup" section, then press the **Restart now** button.

Windows 8.1

a) Select the **Update and recovery** option.

b) Select the **Recovery** option, locate the "Advanced start-up" section, then press the **Restart now** button.

3. Once the computer has rebooted, select the **Troubleshoot** option.

4. Then **Advanced options.**

5. Then **Startup Settings**.

6. Click on **Restart** to restart the computer again**.**

7. A list of startup settings will show up. Select the **Disable driver signature enforcement** option**.**


8. After the computer starts, plug in the Dino-Lite to the USB port.

9. Now open the Device Manager by pressing the Windows key + X keyboard combination and then select **Device Manager** from the menu.


10. Look for devices with yellow "!" or "?" under the "Imaging devices" category. Right click on it and select **Update Driver Software…**

11. In the Update Driver Software window, select the **Browse my computer for driver software** option.

12. Then select the **Let me pick from a list of device drivers on my computer** option.

13. Select the device driver from the model list (**DinoLite Plus and Pro** for AM3XX/AM4XX, or **DinoLite** for AM211) and then press the **Next** button.

Note: If can't find the device driver from the model list, try to manually select the driver by clicking *Have Disk*.   Then select the **snp2std** folder (AM3XX/AM4XX) or **snpstd3** folder (AM211) located at: C:\Program Files (x86)\Common Files\.

14. Select the device driver for your model series (refer below for which device driver to choose) and then press the **Next** button.

- For Dino-Lite Plus and Pro series (AM3XX and AM4XX), choose **DinoLite Plus and Pro** from the model list like the image below.

  Note: If can't find DinoLite Plus and Pro, press on *Have Disk*. Then select the snp2std folder located at: C:\Program Files (x86)\Common Files\snp2std

- For Dino-Lite AM211, choose **DinoLite** from the model list.

  Note: If can't find DinoLlite, press on *Have Disk*. Then select the snpstd3 folder located at: C:\Program Files (x86)\Common Files\snpstd3

15. Now the Windows Security dialog as shown below should pop up. Select **Install this driver software anyway** to continue installation.

16. When the installation is complete a message will show like the one below.